

# **GV-FWC**

Converter for Sending Access Card Data, paired to Face IDs, to Controllers



### Introduction

GV-FWC integrates GeoVision face-recognition-based cameras, software and readers into access control systems by sending access card data, paired to Face IDs, to controllers either through TCP/IP or Wiegand connection. When connected via TCP/IP, a face image is transmitted along with the access data upon face recognition.

Additionally, the alarm output, e.g. a warning light, on GV-FWC can be triggered upon face recognition. For high security applications, GV-FWC can not only pass the face recognition access data to controllers but also require users to swipe paired cards on a connected Wiegand reader for double-authentication.

### **Key Features**

- Connection to controller via TCP/IP / Wiegand
- DC 12 V / PoE+ (IEEE 802.3at)
- Support for up to 4 GV-Face Recognition Cameras / GV-AI FRs / GV-FR Panels
- Alarm trigger upon face recognition of a Face Group
- Connectable to a Wiegand reader for double-authentication, face recognition plus card swipe
- Compatible with 3<sup>rd</sup>-party Wiegand controllers

## **Product Supported**

GV-FWC is required for GV-FR8700-FR / GV-VD8700 to connect to GeoVision access control system. The Wiegand port of GV-FWC allows integration of GeoVision face-recognition-based cameras, software, readers with any 3<sup>rd</sup>-party Weigand controllers.


• Face Recognition Camera: GV-FD8700-FR, GV-VD8700

Software: GV-AI FRReader: GV-FR Panel



## **Diagram**

The following diagram uses GeoVision face recognition cameras as an example to illustrate the integration of video security and access control.



**Specifications** 

n Interface	TCP/IP
faco	2 Wiegand interfaces (In & Out), 26 ~ 64 bits
iace	12 V DC, 900 mA
Input	3 inputs
Output	2 relay outputs
sts Supported	4 GV-FD8700-FR or GV-VD8700 (camera) / GV-AI FR (software) / GV-FR Panel (reader)
	12V DC, 1.25A / PoE+ (IEEE 802.3at, max 25.5 W)
perature	0 ~ 65 °C (32 ~ 149 °F)
nidity	5% ~ 95% RH (non-condensing)
/ x H x D)	130 x 31 x 84 mm (5.11 x 1.22 x 3.30 in)
	170 g (0.37 lb)
	CE, FCC, RoHS
	Input Output sts Supported perature nidity

#### Note:

- 1. GV-FWC can only be connected using CAT-5e cables, TIA/EIA-568-B, with a maximum DC resistance of 9.38 ohms/100 m.
- 2. All specifications are subject to change without notice.



# **Firmware and Software Compatibility**

GV-FWC is compatible with the following firmware and software versions for integration:

GV-AS1520 V2.03 or later GV-AS1620 V1.00 or later GV-CS1320 V3.01 or later GV-EV48 V2.31 or later GV-ASManager access control software V5.1.0 or later GV-AI FR Supported Product / Application Version  GV-AS210 / 2110 / 2120 GV-AS410 / 4110 / 4111 GV-AS810 / 8110 / 8111  Controller  GV-AS1620 V1.02 or later GV-AS1620 V1.02 or later GV-CS1320 V3.04 or later GV-ASManager access control software V5.3.0 or later GV-ASManager access control software V5.3.0 or later GV-ASManager access control software V5.3.0 or later GV-AS410 / 4110 / 4111  Supported Product / Application Supported Product / Application  GV-AS210 / 2110 / 2120 GV-AS410 / 4110 / 4111 GV-AS810 / 8110 / 8111  Controller GV-AS1620 V2.06 or later GV-AS1620 V1.03 or later GV-AS1620 V1.03 or later GV-AS1620 V1.03 or later GV-AS1620 V1.03 or later GV-AS1620 V2.06 or later GV-CS1320 V3.05 or later GV-CS1320 V3.05 or later	Supported Product / Application		Version	
GV-AS810 / 8110 / 8111   GV-AS1520	Controller	GVAS210 / 2110 / 2120		
GV-AS1520   V2.03 or later		GV-AS410 / 4110 / 4111	V2.20 or later	
GV-AS1520 V2.03 or later GV-AS1620 V1.00 or later GV-CS1320 V3.01 or later GV-EV48 V2.31 or later GV-ASManager access control software V5.1.0 or later GV-AI FR Supported Product / Application Version  GV-AS210 / 2110 / 2120 GV-AS410 / 4110 / 4111 GV-AS810 / 8110 / 8111  Controller  GV-AS1620 V1.02 or later GV-AS1620 V1.02 or later GV-CS1320 V3.04 or later GV-ASManager access control software V5.3.0 or later GV-ASManager access control software V5.3.0 or later GV-ASManager access control software V5.3.0 or later GV-AS410 / 4110 / 4111  Supported Product / Application Supported Product / Application  GV-AS210 / 2110 / 2120 GV-AS410 / 4110 / 4111 GV-AS810 / 8110 / 8111  Controller GV-AS1620 V2.06 or later GV-AS1620 V1.03 or later GV-AS1620 V1.03 or later GV-AS1620 V1.03 or later GV-AS1620 V1.03 or later GV-AS1620 V2.06 or later GV-CS1320 V3.05 or later GV-CS1320 V3.05 or later		GV-AS810 / 8110 / 8111		
GV-CS1320 V3.01 or later  GV-EV48 V2.31 or later  GV-ASManager access control software V5.1.0 or later  GV-AI FR  Supported Product / Application Version  GV-AS410 / 4110 / 4111 GV-AS810 / 8110 / 8111  Controller  GV-AS1620 V2.05 or later  GV-AS1620 V1.02 or later  GV-EV48 V2.31 or later  GV-ASManager access control software V5.3.0 or later  GV-ASManager access control software V5.3.0 or later  GV-AS410 / 4110 / 4111 Application  GV-AS410 / 4110 / 4111 Application  GV-AS810 / 8110 / 8111  Controller  GV-AS410 / 4110 / 4111 Application  GV-AS410 / 4110 / 4111 Application  GV-AS410 / 4110 / 4111 Application  GV-AS810 / 8110 / 8111  Controller  GV-AS1620 V2.06 or later  GV-AS1620 V1.03 or later  GV-CS1320 V3.05 or later  GV-CS1320 V3.05 or later  GV-EV48 V2.31 or later		GV-AS1520	V2.03 or later	
GV-EV48   V2.31 or later		GV-AS1620	V1.00 or later	
GV-ASManager access control software  GV-ASI FR  Supported Product / Application  GV-AS210 / 2110 / 2120  GV-AS410 / 4110 / 4111  GV-AS810 / 8110 / 8111  Controller  GV-AS1520  GV-AS1620  GV-AS1620  GV-S1320  GV-EV48  V2.31 or later  GV-EV48  V2.31 or later  GV-ASManager access control software  V5.3.0 or later  GV-FR Panel  Supported Product / Application  GV-AS210 / 2110 / 2120  GV-AS410 / 4110 / 4111  GV-AS810 / 8110 / 8111  Controller  GV-AS1520  V2.06 or later  GV-AS1620  V1.03 or later  GV-AS1620  V2.06 or later  GV-AS1620  V1.03 or later  GV-CS1320  GV-EV48  V2.31 or later		GV-CS1320	V3.01 or later	
Supported Product / Application   Version		GV-EV48	V2.31 or later	
Supported Product / Application         Version           GV-AS210 / 2110 / 2120 GV-AS410 / 4110 / 4111 GV-AS810 / 8110 / 8111         V2.31 or later           Controller         GV-AS1520 GV-AS1620 GV-CS1320 GV-EV48         V2.05 or later           GV-ASManager access control software         V3.04 or later           GV-ASManager access control software         V5.3.0 or later           GV-FR Panel           Supported Product / Application           GV-AS210 / 2110 / 2120 GV-AS410 / 4110 / 4111 GV-AS810 / 8110 / 8111         V2.31 or later           Controller         GV-AS1520 GV-AS1620 GV-AS1620 GV-CS1320 GV-CS1320 GV-EV48         V2.06 or later V2.31 or later	GV-ASManager access control software		V5.1.0 or later	
GV-AS210 / 2110 / 2120 GV-AS410 / 4110 / 4111 GV-AS810 / 8110 / 8111  Controller  GV-AS1520 V2.05 or later GV-AS1620 V1.02 or later GV-CS1320 GV-CS1320 V3.04 or later GV-ASManager access control software V5.3.0 or later  GV-FR Panel  Supported Product / Application GV-AS210 / 2110 / 2120 GV-AS410 / 4110 / 4111 GV-AS810 / 8110 / 8111  Controller  GV-AS1620 V2.06 or later GV-CS1320 GV-AS1620 V1.03 or later GV-CS1320 GV-CS132	GV-AI FR			
Controller  GV-AS410 / 4110 / 4111  GV-AS1520  V2.05 or later  GV-AS1620  V1.02 or later  GV-EV48  V2.31 or later  GV-EV48  V2.31 or later  GV-ASManager access control software  V5.3.0 or later  GV-FR Panel  Supported Product / Application  GV-AS210 / 2110 / 2120  GV-AS410 / 4110 / 4111  GV-AS410 / 8110 / 8111  Controller  GV-AS1620  GV-AS1620  GV-AS1620  V1.03 or later  GV-CS1320  GV-AS1620  V3.05 or later  GV-CS1320  V3.05 or later  V2.31 or later  V2.31 or later	Supported Product / Application		Version	
GV-AS310 / 4110 / 4111   GV-AS310 / 8110 / 8111   GV-AS310 / 8110 / 8111   GV-AS31520   V2.05 or later   GV-AS31620   V1.02 or later   GV-EV48   V2.31 or later   GV-EV48   V2.31 or later   GV-FR Panel   Supported Product / Application   Supported Product / Application   GV-AS210 / 2110 / 2120   GV-AS410 / 4110 / 4111   GV-AS310 / 8110 / 8111   GV-AS310 / 8110 / 8111   GV-AS31620   V2.06 or later   GV-AS31620   V3.05 or later   GV-EV48   V2.31 or l		GV-AS210 / 2110 / 2120		
Controller       GV-AS1520       V2.05 or later         GV-AS1620       V1.02 or later         GV-CS1320       V3.04 or later         GV-EV48       V2.31 or later         GV-ASManager access control software       V5.3.0 or later         Supported Product / Application         Supported Product / Application         GV-AS210 / 2110 / 2120         GV-AS410 / 4110 / 4111       V2.31 or later         GV-AS1520       V2.06 or later         GV-AS1620       V1.03 or later         GV-CS1320       V3.05 or later         GV-EV48       V2.31 or later		GV-AS410 / 4110 / 4111	V2.31 or later	
GV-AS1520 V1.02 or later  GV-CS1320 V3.04 or later  GV-EV48 V2.31 or later  GV-FR Panel  Supported Product / Application Supported Product / Application  GV-AS210 / 2110 / 2120  GV-AS410 / 4110 / 4111  GV-AS810 / 8110 / 8111  Controller  GV-AS1520 V2.06 or later  GV-AS1520 V1.03 or later  GV-CS1320 V3.05 or later  GV-EV48 V2.31 or later		GV-AS810 / 8110 / 8111		
GV-CS1320 V3.04 or later  GV-EV48 V2.31 or later  GV-ASManager access control software V5.3.0 or later  GV-FR Panel  Supported Product / Application Supported Product / Application  GV-AS210 / 2110 / 2120  GV-AS410 / 4110 / 4111  GV-AS810 / 8110 / 8111  Controller  GV-AS1520 V2.06 or later  GV-AS1620 V1.03 or later  GV-CS1320 V3.05 or later  GV-EV48 V2.31 or later	Controller	GV-AS1520	V2.05 or later	
GV-EV48 V2.31 or later  GV-ASManager access control software V5.3.0 or later  GV-FR Panel  Supported Product / Application Supported Product / Application  GV-AS210 / 2110 / 2120  GV-AS410 / 4110 / 4111  GV-AS810 / 8110 / 8111  Controller  GV-AS1520 V2.06 or later  GV-AS1620 V1.03 or later  GV-CS1320 V3.05 or later  GV-EV48 V2.31 or later		GV-AS1620	V1.02 or later	
GV-ASManager access control software  GV-FR Panel  Supported Product / Application  GV-AS210 / 2110 / 2120  GV-AS410 / 4110 / 4111  GV-AS810 / 8110 / 8111  Controller  GV-AS1520  GV-AS1620  GV-AS1620  GV-CS1320  GV-EV48  V5.3.0 or later  V2.31 or later  V2.31 or later  V2.06 or later  V2.06 or later  V3.05 or later		GV-CS1320	V3.04 or later	
GV-FR Panel           Supported Product / Application         Supported Product / Application           GV-AS210 / 2110 / 2120         V2.31 or later           GV-AS410 / 4110 / 4111         V2.31 or later           GV-AS810 / 8110 / 8111         V2.06 or later           GV-AS1520         V1.03 or later           GV-CS1320         V3.05 or later           GV-EV48         V2.31 or later		GV-EV48	V2.31 or later	
Supported Product / Application           GV-AS210 / 2110 / 2120         V2.31 or later           GV-AS410 / 4110 / 4111         V2.31 or later           GV-AS810 / 8110 / 8111         V2.06 or later           GV-AS1520         V1.03 or later           GV-CS1320         V3.05 or later           GV-EV48         V2.31 or later	GV-ASManager	access control software	V5.3.0 or later	
GV-AS210 / 2110 / 2120 GV-AS410 / 4110 / 4111 GV-AS810 / 8110 / 8111 GV-AS1520 GV-AS1620 V1.03 or later GV-CS1320 V3.05 or later GV-EV48 V2.31 or later	GV-FR Panel			
GV-AS410 / 4110 / 4111  GV-AS810 / 8110 / 8111  Controller  GV-AS1520  V2.06 or later  GV-AS1620  V1.03 or later  GV-CS1320  V3.05 or later  GV-EV48  V2.31 or later	Supported Pro	duct / Application	Supported Product / Application	
GV-AS810 / 4110 / 4111  GV-AS810 / 8110 / 8111  GV-AS1520  V2.06 or later  GV-AS1620  V1.03 or later  GV-CS1320  V3.05 or later  GV-EV48  V2.31 or later		GV-AS210 / 2110 / 2120	V2.31 or later	
GV-AS1520         V2.06 or later           GV-AS1620         V1.03 or later           GV-CS1320         V3.05 or later           GV-EV48         V2.31 or later	Controller	GV-AS410 / 4110 / 4111		
GV-AS1520 V2.06 of later  GV-AS1620 V1.03 or later  GV-CS1320 V3.05 or later  GV-EV48 V2.31 or later		GV-AS810 / 8110 / 8111		
GV-CS1320 V3.05 or later GV-EV48 V2.31 or later		GV-AS1520	V2.06 or later	
GV-EV48 V2.31 or later		GV-AS1620	V1.03 or later	
		GV-CS1320	V3.05 or later	
GV-ASManager access control software V5.3. or later		GV-EV48	V2.31 or later	
	GV-ASManager access control software		V5.3. or later	


-3-



## **Packing List**

- 1. GV-FWC
- 2. I/O Wires
- 3. Download Guide
- 4. Warranty Card

## **Overview**



## **Accessories**

Model No.	Name	Details
GV-PA901	PoE Adapter	GV-PA901 PoE adapter is designed to provide power and network connection to IP cameras over a single Ethernet cable.
GV-POE Switch		GV-POE Switch is designed to provide power along with network connection for IP devices. The GV-POE Switch is available in various models with different numbers and types of ports.
Power Adapter		Contact our sales representatives for the countries and areas supported.
The following Wie	egand readers can connec	t to GV-FWC for double-authentication application, face recognition plus card swipe.
GV-CR420	IP Camera Reader	GV-CR420 is a card reader with built-in 4 MP wide angle IP camera that is able to transmit a wide-angle live view for enhanced access control management.
GV-DFR1352	Door Frame Card Reader	GV-DFR1352 is a card reader designed to be installed on the door frame or recognizing access cards.
GV-R1352	Card Reader	GV-R1352 is a card reader, featured with Wiegand and RS-485 outputs, designed to recognize access cards.
GV-Reader1251	Card Reader	GV-Reader1251 is a card reader that supports 125-kHz access cards for access control management
GV-RK1352	Card Reader	GV-RK1352 is a 13.56 MHz card reader with keypad. The reader has both Wiegand and RS-485 outputs that can be connected to any standard access control panel.
GV-RKD1352	Card Reader	GV-RKD1352 is a 13.56 MHz card reader with keypad. The reader has both Wiegand and RS-485 outputs that can be connected to any standard access control panel. It also supports OSDP communication and DESFire EV2 card.
GV-SR1251	Card Reader	GV-SR1251 is a card reader that supports 125-kHz access cards for access control management.

-4-