



ODYSSEY

Hardware Accessories RS422/485

Used at the PC to convert RS485 signal levels to RS232 when connecting JUNO NET panels to ODYSSEY using this interconnection technology. The unit is port powered and hence no external power is required.

12 V DC nominal - Does not require external supply
3 mA + transmission load current
Half Duplex - 4 wire
9600 baud - 8 data bits - 1 stop bit - no parity
IP44
RS232 side DB9 Female - RS485 side DB9 Female
95% RH Non-Condensing
-10ºC to 50ºC
78 (L) x 43 (W) x 20 (H) mm
40 g

ORDER CODE	
RS422/485 CONVERTER	RS232 TO RS422/485 CONVERTER - MODEL 4WSD9R

